



Part Number – 300010

Application – 6.6L Duramax

Fluidampr High Strength Bolt & Friction Washer Installation

- 1) Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- 2) Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit and length.
- 3) To ensure proper thread engagement and accurate torque readings, clean the threads in the end of the crankshaft. Chase if necessary with a thread chaser or tap.
- 4) Install supplied Fluidampr friction washer onto crankshaft, install damper per damper installation instructions.
- 5) Lubricate the threads of the bolt, the under head of the bolt and the front face of the damper (where the washer contacts the damper) with Anti-Seize. Install the washer onto the bolt then install the bolt hand tight. Fluidampr does not recommend the use of an impact wrench to tighten.
- 6) Torque the damper bolt to **325 Ft. Lbs. or 75 Ft. Lbs. plus 90°**

If you have any questions please contact Fluidampr customer service at

Fluidampr – 180 Zoar Valley Road, Springville, NY 14141

Ph: 716-592-1000 – Email: support@fluidampr.com